



## **FIXING INSTRUCTIONS**

### **HORIZONTAL SLIDING UNIT**

#### **INSTALLATION INTO STONE/BRICK**

1. Clean down existing opening.
2. Drill reveals, head and bottom of the aperture and insert plastic plugs (which will not expand when damp)
3. Insert CS1 track and secure with plated screws to left-hand and right-hand jambs and also to the head of the unit.
4. Secure each section with a minimum of 2 plated screws (dependent on height and width of window).
5. Secure S121 (lower track) to the bottom of the window using 1 or more plated screws (dependent on the width of the window).
6. The unit is then sealed into the aperture with decorators caulk.
7. Sliding panels are then engaged fully into the top track and lowered into the lower track.

No fixings can be seen.