



STORM

BESPOKE SECONDARY GLAZING

FIXING INSTRUCTIONS

HORIZONTAL SLIDING UNIT

INSTALLATION INTO TIMBER

1. Clean down existing opening.
2. Insert CS1 track and secure with wood screws to left-hand and right-hand jambs and also to the head of the unit.
3. Secure each section with a minimum of 2 wood screws (dependent on height and width of window).
4. Secure S121 (lower track) to the bottom of the window using 1 or more wood screws (dependent on the width of the window).
5. The unit is then sealed into the aperture with decorators caulk.
6. Sliding panels are then engaged fully into the top track and lowered into the lower track.

No fixings can be seen.