



STORM

BESPOKE SECONDARY GLAZING

FIXING INSTRUCTIONS

SLIMLINE UNIT (INTO STAFF BEADS)

INSTALLATION INTO TIMBER

1. Clean down existing opening.
2. Insert light gauge aluminium angles (full height of aperture) to both left-hand and right-hand jambs.
3. Place the top channel (full width of aperture) into the top staff beads.
4. Secure each side and top with a minimum of 2 wood screws (dependent on height and width of window).
5. The secondary glazed unit is then offered into the aperture to check if the aluminium angles need to be adjusted. The unit is then removed and any adjustments are then made.
6. Once the angle gives the best fit, the sides and top channel are then sealed into place with decorators caulk.
7. The unit is then placed into the framework – held with the magnets and top channel.

No fixings can be seen. However, on larger windows, it may be necessary to secure the secondary glazed unit at the cill or transom line.